

Mini salmon pâte sandwiches



Ingredients (serves 1)

Pan de molde sin corteza

Un trozo de salmón

Pepino

Tomate

Crema de queso

Aceite de oliva virgen extra

Method

1. Peel cucumber and cut lengthwise. Use a spoon to remove seeds.
2. Cut tomato in half. Remove seeds and grate.
3. Cook salmon (steam, microwave, or sauté with a little oil). Let cool and shred.
4. Place salmon, cucumber, a little bread, oil, and cream cheese in a blending container and purée, adding water if necessary.
5. Spread purée onto bread slices. Build sandwich and serve.

Recommendations

The same recipe can be followed to make chicken or avocado pâté sandwiches.